

# Winterizing Instructions

Winterizing (Generally the first week of November)

1. Close irrigation supply valve by turning clockwise with shut off key until snug
2. Open test cocks by using flat head screw driver to turn screws 45 degrees in any direction
3. Turn ball valves 1/8 turn (45 degrees) to winterized position (as shown)
4. Open drain valves by turning counter-clockwise until snug

Activation (Generally Middle of March)

1. Close drain valves by turning clockwise until snug
2. Open ball valves
3. Close test cocks
4. Open irrigation supply valve
5. Watch and listen for leaks

